aranet

SENSOR DATA

WIFI

LAN

12V

POWER FROM BATTERY

OFF ON ⊖–⊂–⊕ LAN RESET

Aranet PRO base station

Quick start guide

1.

SENSOR DATA
WIFI
LAN
12V
POWER FROM BATTERY

OFF ON ⊖-⊙-⊕ LAN RESET ⊷←

2.

A

B

C

PZ2

3.

4.

① ON

🕐 10 sec

② — WIFI

○ — SENSOR DATA
● — WIFI
○ — LAN
● — 12V
○ — POWER FROM BATTERY

OFF ON ⊖–⊜–⊕ LAN RESET ⟵•⟶

5.a

① 📶 WiFi SSID: Aranet-******

② 🌐 URL: http://192.168.206.100

③
Login
Username
root
Password
••••••••
☑ Remember me   LOGIN

Username: root
Password: **********

△ aranet
▌▌▌▌▌▌▌▌▌▌▌▌▌▌▌▌
WiFi SSID: Aranet-5e63aa
WiFi IP: 192.168.206.100
ETH IP: 192.168.205.100
ETH MAC: C493000A2592
Username: root
Password: nMbgvcwxM3

PRO base station
Made in Latvia, EU
www.aranet.com
M/N:TDSBWB01
S/N: 349681000113   CE

🗑

12V ⎓ 0.5A

5.b

① 📶 WiFi SSID: Aranet-******

② 🌐 URL: http://192.168.206.100

③
Login
Username
root
Password
••••••••
☑ Remember me   LOGIN

Username: root
Password: changeme

△ aranet
PRO Base   www.aranet.com
                  Made in Latvia, EU
▌▌▌▌▌▌▌▌▌▌▌▌▌▌▌▌
M/N:TDSBWPA1.012
S/N:349681 003529
CE UK CA 🗑   12V ⎓ 0.5A

Smarter
than others

aranet

SCAN THE QR CODE TO SEE
PRO BASE USER GUIDE

SCAN THE QR CODE TO SEE
HOW TO PAIR SENSORS TO THE
ARANET PRO / PRO PLUS BASE STATION